

SEE-THRU STRIP CURTAIN ASSEMBLY INSTRUCTION SHEET

FOR ½ OVERLAP ONLY 8" strip .080 Mil Thick

PLEASE READ INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING

1. Insert support brackets into channel track, making sure studs are facing same direction.
2. Bolt end stops on to channel track where holes are drilled at each end.
3. Suspend SB500 support bracket from door lintel, threaded rod, chain, cable, etc.
4. Starting with the first stud on the left-hand end, (as you face the curtain) mount the first row of See-Thru strips, making sure the strip curvature is facing toward you. (Concave)

There should be a four (4) inch spacing (or 2 studs) between strips of the first row.

5. Starting with the fourth stud on the left-hand end, (determined as in step one) mount the top (overlapping) row of See-Thru strips, making sure the strip curvature is facing away from you. (Convex)

There should be a four (4) inch spacing between strips of the second (overlapping) row.

6. Align segmented frontal plates over studs and See-Thru strips. Secure and tighten frontal plates with hex nuts.

We recommend that installation of strips (steps 4,5, & 6) be done in three to four foot sections.

ASSEMBLED CURTAINS SHOULD HAVE A CONCAVE / CONVEX OVERLAP **

This type of overlap provides for proper seal between each strip.

